PTO Relay Setup

|			
	85	**86**	PTO Wire
Ground	**Relay**		
	30	**87**	Device Input Wire

Pins 85 and 86 may be reversed.

Pin Configuration

```
          87
         ___
  86     87a     85
   |     ___      |
         30
          |
```